

THE AUTHENTIC T-SHIRT COMPANY® Polypropylene Grocery Tote - B1011

Product Features:

- 100 gram, 100% non-woven polypropylene
- Extra handle reinforcement for heavier loads
- Square bottom allows tote to sit upright
- Double-stitched seams and tonal binding around edges for durability
- Handles for over-the-shoulder or hand carry
- Large decoration area
- Weight capacity: 5kg

Comparable styles:








B1010 – Polypropylene Tote
B1012 – Polypropylene Mini Tote

Fabric Features / Details:



Available Colours and PMS Colours

Textile fabric colours are subject to dye lot variation and will not be exact match to print pantone reference

Black	Hunter	Lime	Peanut
			
Black 6C	3435C	368C	A little lighter than 4645C
Raspberry	Red	Royal	
			
214C	1795C	7685C	



June 2013

Due to the nature of polypropylene fabric, special care must be taken throughout the decoration process

TIPS FOR EFFECTIVELY DECORATING POLYPROPYLENE FABRICS

Due to the nature of polypropylene fabrics, special care must be taken throughout the decoration process. Here are some tips to effectively decorate polypropylene products. Screen Printing or Heat Transfer are recommended/preferred decoration options



Screen Printing Tips

- Bag/garment temperature must not exceed 270-290°F. Exceeding this temperature will cause the fabric to shrink, become wavy or melt.
- Although possible to do more, only one color screen print is recommended.
- Dryer temperature and belt speeds must be changed accordingly. If flashing these products, do not exceed 1-2 seconds. Anything longer may damage the fabric as stated above.
- This fabric requires the use of specialty lower curing fast fusion poly inks. Please consult your ink supplier for more information.
- Polypropylene requires a longer cooling time than cotton. Failure to cool the fabric prior to stacking into a printer's fold may cause the fabric and applied ink to stick together.



Heat Transfer Tips

- For multiple colors, specialty heat transfer application is most common. This specialty transfer will cure at 250°F for 5-7 seconds. Please consult with your heat transfer supplier. If you heat press these fabrics, you must adjust the time, temperature and pressure. Failure to do so may damage the fabric as stated above.
- A test sample run is recommended, especially if you have a large order or if your printer does not specialize in printing on polypropylene fabrics.