



**DF7670L**

**Product Features:**

- 15.5-oz, 100% polyester fleece
- 5.4-oz, 100% DWR nylon panels at upper body, sleeves and hem
- Reflective **DRYFRAME** on bottom left hem
- Zippered hand pockets with polyester tricot lining
- Drawcord and toggles at hem

Ladies' sizes: XS-4XL



**Icons/Fabric Features:**



**Available Colours and PMS Colours**

Textile fabric colours are subject to dye lot variation and will not be exact match to print pantone reference

BLACK / BLACK

ASPHALT / BLACK



WARMTH RATING	MILD	● WARM	WARMER	WARMEST
WATER PROTECTION	● WATER RESISTANT PANELS		WATERPROOF	
WIND RESISTANT	YES			
WIND AND WATER PROTECTION	DWR PANELS			

Due to the nature of nylon, special care must be taken throughout the decoration process.

## DF7670L - DRYFRAME® Huron Fleece Tech Ladies' Jacket

### GARMENT MEASUREMENTS

Size	XS	S	M	L	XL	2XL	3XL	4XL
Chest - Half Measure	19"	20"	21"	22 1/2"	24"	25 1/2"	27 1/2"	29 1/2"
Chest - Full Measure	38"	40"	42"	45"	48"	51"	55"	59"
Body Length from HPS (At Front)	26"	26 1/2"	27"	28"	29"	30"	30 1/2"	31"
Sleeve Length-CB	33"	33 1/2"	34"	34 1/2"	35"	35 1/2"	36"	36 1/2"

*Finished measurements in inches. Refer to "How to Measure" guide for detailed information on measurement instructions.*

### LADIES' General Sizing Guide

Size	XS	S	M	L	XL	2XL	3XL	4XL
Numeric Size	2	4-6	8-10	12-14	16	18-20	22	24
Bust	32"-34"	35"-36"	37"-38"	39"-41"	42"-44"	45"-47"	48"-51"	52"-55"
Waist	24"-25"	26"-27"	28"-30"	30"-32"	33"-35"	36"-38"	40"-42"	42"-44"
Hip	33"-35"	35"-37"	37"-39"	39"-41"	42"-44"	45"-47"	48"-50"	50"-52"
Sleeve Length-CB	30"-30 1/2"	30 1/2"-31"	31 1/2"-32"	32 1/2"-33"	33 1/2"-34"	34"-34 1/2"	34 1/2"-35"	34 1/2"-35"



### PRINTING INSTRUCTIONS FOR NYLON FABRICS

**Due to the nature of Nylon fabric, special care must be taken throughout the decoration process. Special care must be taken during the decoration process and after.**

Here are some tips to effectively decorate these products.

#### Heat Transfer/Screen Printing:

- Garment temperature must not exceed 310°F or 154°C.
- Use fast fashion/low cure temperature ink to help prevent the need for a higher temperature to cure the ink.
- A test sample run is recommended in all printing processes, especially if you have a large order or if your printer does not specialize in printing on Nylon fabrics.